

1

Reset Cintiq

Reset Cintiq to factory default settings. You need to do this everytime you use the machine.

Locate the On Screen Display (OSD) controls on the top of the Cintiq

Press the RESET button

Press the Arrow button to select YES

Press Select



Apple Cintiq Monitor Color Profile



2

Copy Profile

Download the generic .icc profile for your room location.

By default the library folder is invisible. To reveal your Library hold down the option key while selecting the Go pull-down menu in the finder.

Copy your profile to your Library > ColorSync > Profiles folder



3

Apply Profile

You will need to check that your profile has been correctly applied everytime you log in. For a machine specific profile checkout the color munki calibration device from digital checkout and create your own.

Launch Systems Preferences and select Displays

Click the Color tab

Select your desired profile

Close System Preferences

